


Jitbesked.dk

QNAP med firmware version: 3.2.6 Build 0423T

1. Start ud med at logge ind på din QNAP server og derefter naviger videre til:



2. Udfyld "Configure SMSC SERVER"

Notification

CONFIGURE SMTP SERVER **CONFIGURE SMSC SERVER** ALERT NOTIFICATION

Configure SMSC Server

You can configure the SMSC settings to send instant system alerts via the SMS service provided by the SMS provider.

SMS Service Provider:

SMS Service Provider: (The name you enter will be shown on the list of SMS service provider.)

URL Template Text:

Note: You will not be able to receive the SMS properly if the URL template text entered does not follow your SMS service provider's format.

Se "URL Template Text" beskrevet nedenfor.

URL Template Replaceable Parameters:	
@@UserName@@	The user name configured for this connection (optional)
@@Password@@	The password configured for this connection (optional)
@@PhoneNumber@@	The phone number of the recipient to receive this SMS message (required)
@@Text@@	The text of the SMS message (required)

URL template Text :

https://www.jitbesked.dk/ssl/10/services/sendsms.php?message=@@Text@@&receiver=@@PhoneNumber@@&user=@@UserName@@&password=@@Password@@

Teknisk info for test. Har man problemer med at få det til at virke kan man benytte følgende URL template text for at teste.

https://www.jitbesked.dk/ssl/10/services/sendsms.php?message="Hej"&receiver=45xxxxxx&user=XXXXXX&password=XXXXXX&Dummy=@@PhoneNumber@@

3. Enable SSL Connection

Notification

CONFIGURE SMTP SERVER CONFIGURE SMSC SERVER ALERT NOTIFICATION

Configure SMSC Server

You can configure the SMSC settings to send instant system alerts via the SMS service provided by the SMS provider.

SMS Service Provider: JITBESKED [EDIT] [DELETE]

Enable SSL Connection

SSL Port: 443

SMS Server Login Name: [Input Field]

SMS Server Login Password: [Input Field]

Indtast username fra JIT-EMAIL

Indtast password fra JIT-EMAIL

OBS : husk at sætte flueben i "Enable SSL Connection"

JIT EMAIL

Når du starter JitBesked, skal du indtaste denne licensnøgle :

[redacted] [redacted]

Du har desuden fået tilknyttet aftale nr.: [redacted] som du bedes oplyse

Username Password

4. ALERT NOTIFICATION

Notification

CONFIGURE SMTP SERVER **CONFIGURE SMSC SERVER** **ALERT NOTIFICATION**

Alert Notification

When a system event occurs, an alert email/SMS will be sent automatically.

Send system error alert by:

Send system warning alert by:

E-mail Notification Settings

E-mail address 1:

E-mail address 2:

Note: The SMTP server must be configured first for alert mail delivery.

SMS Notification Settings

Country Code:

Cell Phone No. 1: +45

Cell Phone No. 2: +45

1. tast mobilnummer på 1 modtager

2. Send en TEST SMS

* must configure the SMSC server to be able to send SMS notification properly.